

USE & CARE INSTRUCTIONS

SWISS+TECH®
BodyGard®
Multi-Function Emergency Tools



5-in-1

7-in-1

- **High-Carbon Steel Components** – long lasting!
- **Tough ABS Construction** for rugged use.
- **Glow in the Dark** to help locate in low or no light conditions. (Expose to light daily for best results.)



Carry it on your key ring so it's always with you when you need it!

Attach the included Key Ring to your BodyGard® quick-release Seat Belt Cutter cover and secure the unit to your key chain, so it's with you whenever you drive and wherever you take your keys.

For quick and easy access, you can also attach your BodyGard® to your vehicle's rear-view mirror post or driver-side sun visor arm, and even add an extra one to the passenger-side sun-visor arm.

BEFORE USING, REMOVE PULL TAB TO ACTIVATE BATTERY.

Firmly grasp Pull Tab extending out of the Battery Door and pull completely out of unit. Your SWISS+TECH® BodyGard® is now operational.



Built-in QUICK RELEASE for immediate emergency use.

Grasp BodyGard® firmly, and with a sharp tug, pull it away from Key Ring.

1 SEAT BELT CUTTER

- Pull BodyGard® away from key ring. This exposes safety blade chamber.
- Place and hold outer edge of seat belt strap inside blade chamber.
- Grasping BodyGard® firmly, Pull blade quickly across strap to cut completely.

NOTE: Intended only to cut seat belt webbing if a seat belt does not unlatch during a vehicular accident. Safety blade designed to prevent accidental or intentional cutting. Blade type permitted on aircraft (carry-on and checked) per USDHS, TSA Rev. 12-1-2005.



2 Automatic GLASS BREAKER

- Pull BodyGard® away from key ring.
- Press barrel firmly against vehicle side window.
- Breaker point automatically deploys to break glass.
- Push out any remaining broken glass to escape.

IMPORTANT: Intended only to break tempered automobile door window glass during a vehicular accident. Unit will not break windshields or other windows made of laminated glass. Use in an emergency only. DO NOT use for any other purpose. This is not a toy.



3 SONIC ALARM

TO TURN OFF ALARM – HOLD BUTTON FOR 3 SECONDS

- Locate the button with the “alarm” symbol on the front of your BodyGard®.
 - Press once to activate alarm.
 - Press again and hold for three seconds to turn off.
- CAUTION:** Device emits loud noise to aid in warding off attack. DO NOT place near ears. **NOTE:** Be sure speaker on back is not obstructed.



4 Bright-White LED FLASHLIGHT

- Locate the button with the “lamp symbol” on the front of your BodyGard®.

BodyGard® 5-in-1:

- Press 1 time to turn on flashlight.
- Press again 2 times to turn off.

BodyGard® 7-in-1

- Press 1 time to turn on flashlight low beam.
- Press 2nd time for flashlight high beam.
- Press again 2 times to turn off.



5 RED DISTRESS FLASHER

- Locate the button with the “lamp symbol” on the front of your BodyGard®.

BodyGard® 5-in-1:

- Press 2 times to activate the red distress flasher.
- Press again to turn off.

BodyGard® 7-in-1

- Press 3 times to activate the red distress flasher.
- Press again to turn off.



6 THERMOMETER

(BodyGard® 7-in-1 only)

- Locate the easy-to-read thermometer on the front of your BodyGard® 7-in-1.
- The red arrow points directly to the correct temperature on the scale.

Note: The temperature is measured in degrees Fahrenheit, each marking equals 5 degrees.



7 DIGITAL TIRE GAUGE

(BodyGard® 7-in-1 only)

- Press Tire Gauge button to activate all digits until “0.0 PSI” appears on LCD readout (default unit of measure is PSI).
- Push Tire Gauge Nozzle onto tire valve. Be sure to make a good seal between the nozzle and the valve stem so no hissing sound of escaping air is heard.
- Hold Gauge on valve stem for about 3 seconds until the pressure reading displayed is stable.
- Pressing the button will change the unit of measure in the following sequence: PSI > BAR > KPA > KG/CM2 > PSI (Note: changing the unit of measure may also change the number of digits displayed).
- To turn off Tire Gauge, press and hold button for 3 seconds, or wait 15 seconds for automatic shutoff.



Replacing the battery

- Using a Philips head screwdriver (eyeglass or jeweler's size), open the battery compartment on the back of your BodyGard®.
- Remove the battery and replace with the identical type and size: A23/12V alkaline



SWISS+TECH® Limited LIFETIME Warranty

This product is covered by a limited lifetime warranty to the original purchaser in that this product is free from defects in workmanship and materials. During the warranty period, this product will either be repaired or replaced with a product of equal or greater value.

Damage through normal wear and tear (including battery expiration and surface coatings), repair or alteration, misuse, abuse, neglect, accident, improper storage and handling, fire, negligence, improper cleaning, circumstances not directly attributable to manufacturing defects, or act of God is not included.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR ISSUE.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Simply return your SWISS+TECH® brand product postpaid and insured to: Swiss+Tech Products
701 Beta Drive, Unit 5
Cleveland, Ohio 44143

Our micro-tools are great to own and make terrific gifts! Discover more of them at select retailers, or at:

www.swisstechtools.com

Patent Pending. Made in China. SWISS+TECH® and BodyGard® are registered trademarks of Crestwood Partners, LLC. Specifications are subject to change without notice. © 2007 Crestwood Partners, LLC, Cleveland, OH 44143 1-800-414-8799